

Programming The Time & Date

- The time operates on a 24 hour clock.
- **The new time may not be displayed for a few minutes afterwards!**

Keypad Instructions:

Step 1: **[*]**

Step 2: **[6]**

Step 3: **[Master Code]- 4 digit code of owner/manager**

Step 4: **[1]**

Step 5: **[hh:mm:MM:DD:YY]**

[hour / minute / month / day / year]

Step 6: **[#] [#]**

Example: Set time for 8:05am March 28, 2008 using mastercode of 5678

[*] [6] [5678] [1] [08 05 03 28 08] [#][#]

Example: To set time for 1:26 pm May 2, 2008 using mastercode of 5678

[*] [6] [5678] [1] [13 26 05 02 08] [#][#]